


Fundamentals of Electronics

ECE 101



The Transistor


Amplification and switching

Transistor

- Key characteristic:

- The transistor is a three-terminal device with the feature that the current through two terminals can be controlled by small changes we make in the current or voltage at the third terminal.
- This control feature allows us to amplify small ac signals or to switch the device from an *on* state to an *off* state and back.
- These two operations, amplification and switching, are the basis of a host of electronic functions.
- This forms the basis for both bipolar junction transistors (BJT) and field effect transistors (FET).





The transistor action - 1



$$V_i = I \times \underline{r} \quad V_o = I \times \underline{R}$$
$$V_i < \underline{V_o} \quad (\text{amplification})$$

Active mode
 $J_1 \rightarrow f.b. \quad R_{es} = 0$
 $J_2 \rightarrow \gamma.b. \quad R_{es} = \infty$

The transistor action - 2





- If an ac source is added to the control voltage
 - We can achieve large variations in i_D by making small changes in V_G
 - For example if V_G changes by value of 0.25V, V_d varies about its dc 2V.
 - Thus the amplification of the ac signal is $2/0.25 = 8$.
 - we can switch from the bottom of the load line to almost the top by appropriate changes in V_G .

For BJTs, this kind of control is achieved by current control.


Field Effect Transistors

The idea


Junction Field Effect Transistor: JFETs



$$v_d = \frac{I}{neA}$$




Gate control






Pinch-off

MOSFET (Metal–Oxide–Semiconductor Field-Effect Transistor)



MOSFET




Different regimes as V_D is varied.





Field Effect Transistors




Characteristics



Different regimes as V_D is varied.




Pinch-off



MOSFET (Metal–Oxide–Semiconductor Field-Effect Transistor)

N-Channel MOSFETs use electron flow as the charge carrier. P-Channel MOSFETs use hole flow as the charge carrier, which has less mobility than electron flow.

Symbols




4-terminal

Simplified

Simplified

n-channel MOSFET






4-terminal

Simplified

Simplified

p-channel MOSFET

MOSFET Band Diagram





N-channel MOSFET



Most transistors operate by controlling the height of an energy barrier with an applied voltage.

Note: that there is a potential energy barrier that separates electrons in the source from electrons in the drain.

Application of a positive voltage



MOSFET Characteristics



Thank you